

Kramer Electronics, Ltd.



USER MANUAL

Model:

VP-505

3G HD-SDI to Video Scan Converter

Contents

1	Introduction	1
2	Getting Started	1
2.1	Quick Start	2
3	Overview	3
4	Defining the VP-505 3G HD-SDI to Video Scan Converter	4
5	Connecting the VP-505 3G HD-SDI to Video Scan Converter	5
6	Operating the VP-505 3G HD-SDI to Video Scan Converter	6
6.1	Using the Front Panel Buttons	6
6.2	Using the OSD	6
6.2.1	The Main Menu	7
6.2.2	The Display Submenu	7
6.2.3	The Color Submenu	8
7	Technical Specifications	9

Figures

Figure 1:	VP-505 3G HD-SDI to Video Scan Converter Front Panel	4
Figure 2:	VP-505 3G HD-SDI to Video Scan Converter Rear Panel	4
Figure 3:	Connecting the VP-505 3G HD-SDI to Video Scan Converter	5

Tables

Table 1:	VP-505 3G HD-SDI to Video Scan Converter Front Panel Features	4
Table 2:	VP-505 3G HD-SDI to Video Scan Converter Rear Panel Features	4
Table 3:	The Main Menu Parameters and Functions	7
Table 4:	The Display Submenu Parameters	7
Table 5:	The Color Submenu Parameters	8
Table 6:	Technical Specifications of the VP-505 3G HD-SDI to Video Scan Converter	9

1 Introduction

Welcome to Kramer Electronics! Since 1981, Kramer Electronics has been providing a world of unique, creative and affordable solutions to the vast range of problems that confront the video, audio, presentation and broadcasting professional on a daily basis. In recent years, we have redesigned and upgraded most of our line, making the best even better! Our 1,000-plus different models now appear in 11 groups¹ that are clearly defined by function.

Thank you for purchasing your Kramer MegaTOOLS® **VP-505 3G HD-SDI to Video Scan Converter** which is ideal for:

- Projection systems in conference rooms, boardrooms, hotels and churches
- Monitoring of SDI signals using cheap video displays
- Displaying down-scaled SDI in legacy systems
- Making video recordings of SDI content

The package includes the following items:

- **VP-505 3G HD-SDI to Video Scan Converter**
- Power adapter
- This user manual²

2 Getting Started

We recommend that you:

- Unpack the equipment carefully and save the original box and packaging materials for possible future shipment
- Review the contents of this user manual
- Use Kramer high-performance, high-resolution cables³

1 GROUP 1: Distribution Amplifiers; GROUP 2: Switchers and Matrix Switchers; GROUP 3: Control Systems; GROUP 4: Format/Standards Converters; GROUP 5: Range Extenders and Repeaters; GROUP 6: Specialty AV Products; GROUP 7: Scan Converters and Scalers; GROUP 8: Cables and Connectors; GROUP 9: Room Connectivity; GROUP 10: Accessories and Rack Adapters; GROUP 11: Sierra Products

2 Download up-to-date Kramer user manuals from <http://www.kramerelectronics.com>

3 The complete list of Kramer cables is available at <http://www.kramerelectronics.com>

2.1 Quick Start


This quick start chart summarizes the basic setup and operation steps.

VP-505 Quick Start Guide

This page guides you through a basic installation and first-time use of your **VP-505**. For more detailed information, see the **VP-505** user manual, the latest version of which can be downloaded from <http://www.kramerelectronics.com>.

Step 1: Check what's in the box

- The **VP-505** 3G HD-SDI to Video Scan Converter
- 1 power adapter (5V DC input)
- 1 Quick start guide
- 1 User Manual




Save the original box and packaging materials in case your Kramer product needs to be returned to the factory for service.

Step 2: Install the VP-505

Mount the **VP-505** in a rack (using the optional RK-T2B rack adapter) or place on a table.

Step 3: Connect the inputs and outputs

Always switch off the power to each device before connecting them to your **VP-505**.



For best results, we recommend that you always use Kramer high-performance cables to connect AV equipment to your **VP-505**.


Step 4: Connect the power



Connect the 5V DC power adapter to your **VP-505** and plug the adapter into the mains electricity. Switch on the power to each device.

Step 5: Operate the VP-505

Set the parameters using the front panel buttons and the On-screen Display (OSD):



3 Overview

The Kramer **VP-505** *3G HD-SDI to Video Scan Converter* is a high-quality scan converter for down-scaling SDI, HD-SDI and 3G HD-SDI signals to PAL or NTSC video.

The **VP-505** also features:

- A maximum data rate of 3Gbps
- An SDI input
- An equalized and re-clocked loop output (up to 3G HD-SDI)
- Multi-standard operation: SDI (SMPTE 259M and SMPTE 344M), HD-SDI (SMPTE 292M) and 3G HD-SDI (SMPTE 424M)
- Simultaneous high-quality composite video and s-Video (Y/C) outputs
- A unbalanced stereo audio output
- An OSD (On-screen Display) accessible via the front panel buttons for easy setup and adjustment
- A built-in ProcAmp for convenient signal adjustment
- A non-volatile memory that retains the last settings used
- A freeze button
- An external 5V DC source, making it suitable for field operation
- Operation directly via the front panel push buttons and the OSD

To achieve the best performance:

- Use only good quality connection cables¹ to avoid interference, deterioration in signal quality due to poor matching, and elevated noise levels (often associated with low quality cables)
- Avoid interference from neighboring electrical appliances that may adversely influence signal quality
- Position your Kramer **VP-505** away from moisture, excessive sunlight and dust



Caution: No operator serviceable parts inside the unit

Warning: Use only the Kramer Electronics input power wall adapter that is provided with the unit

Warning: Disconnect the power and unplug the unit from the wall before installing

¹ Available from Kramer Electronics at <http://www.kramerelectronics.com>

4 Defining the VP-505 3G HD-SDI to Video Scan Converter

[Figure 1](#) and [Table 1](#) define the front panel of the **VP-505**.




Figure 1: VP-505 3G HD-SDI to Video Scan Converter Front Panel

Table 1: VP-505 3G HD-SDI to Video Scan Converter Front Panel Features

#	Feature	Function
1	ON LED	Lights green when the unit is powered on
2	SDI LED	Lights blue when an SDI signal is detected on the input
3	MENU Button	Press to display the OSD (On-screen Display) menu. When the OSD is not displayed, press together with the – button to set the output resolution to NTSC
4	ENTER Button	In the OSD, press to select the highlighted menu item. When the OSD is not displayed, press together with the + button to set the output resolution to PAL
5	– Button	In the OSD, press to step up through the options or to decrement the parameter value
6	+ / FREEZE Button	In the OSD, press to step down through the options or to increment the parameter value. When the OSD is not displayed, press to freeze the display

[Figure 2](#) and [Table 2](#) define the rear panel of the **VP-505**.




Figure 2: VP-505 3G HD-SDI to Video Scan Converter Rear Panel

Table 2: VP-505 3G HD-SDI to Video Scan Converter Rear Panel Features

#	Feature	Function
1	SDI IN BNC Connector	Connect to the SDI source
2	SDI OUT BNC Connector	Connect to the SDI acceptor (loop). The signal is re-clocked and equalized

#	Feature	Function
3	AUDIO OUT RCA Connectors	LEFT Channel Unbalanced Stereo Audio
4		RIGHT Channel Unbalanced Stereo Audio
5	CV OUT BNC Connector	Connect to the composite video acceptor
6	Y/C OUT 4-pin Connector	Connect to the Y/C (s-Video) acceptor
7	5V DC	Connect to the power adapter, center pin positive

5 Connecting the VP-505 3G HD-SDI to Video Scan Converter



Always switch off the power to each device before connecting them to your **VP-505**. After connecting your **VP-505**, connect its power and then switch on the power to each device.




Figure 3: Connecting the VP-505 3G HD-SDI to Video Scan Converter

To connect the VP-505, as illustrated in the example in [Figure 3](#):

1. Connect the SDI video source (for example, a digital camera) to the SDI IN BNC connector.
2. Connect the SDI OUT BNC connector to the SDI acceptor (for example, an SDI display).

3. Connect the LEFT and RIGHT AUDIO OUT RCA connectors to the audio acceptor (for example, a stereo audio amplifier).
4. Connect the VIDEO CV OUT BNC connector to the composite video acceptor (for example, a composite video display).
5. Connect the VIDEO Y/C OUT 4-pin connector to a Y/C (s-Video) acceptor (for example, an s-Video recorder).
6. Connect the power adapter to the 5V DC power socket and to the mains electricity (not shown in the illustration).

6 Operating the VP-505 3G HD-SDI to Video Scan Converter

The **VP-505** is operated directly via the front panel buttons and via the OSD menu (see [Section 6.2](#)).

6.1 Using the Front Panel Buttons

During normal operation (without the OSD), the front panel buttons perform in the following manner:

- **MENU**: Displays the OSD Main Menu (see [Section 6.2](#)). Press a second time to close the OSD
- **FREEZE**: Freezes the display. Press a second time to unfreeze the display
- **MENU** and **-**: Press together to set the output to NTSC
- **ENTER** and **FREEZE**: Press together to set the output to PAL

6.2 Using the OSD

The OSD is used to set a variety of parameters.

When using the OSD, the front panel buttons operate in the following manner:

- **MENU**: Opens the OSD main menu (see [Table 3](#)). Press a second time to close the OSD
- **ENTER**: Selects the highlighted menu item or parameter
- **-**: Steps up through the menu list or decrements the parameter value
- **+**: Steps down through the menu list or increments the parameter value

Note: After a period of 15 sec with no button activity, the OSD menu times-out automatically.

Example of Using the OSD Menu

To set the green offset value of the display output (for example, to 42):

1. From normal operation, press **MENU**.
The OSD main menu appears on the screen.
2. Press the **+** or **-** button to highlight **COLOR**.
COLOR changes to green.
3. Press **ENTER**.

- The Display submenu is displayed.
4. Press the + or – button to highlight G OFFSET.
G OFFSET changes to green.
 5. Press ENTER.
The G OFFSET parameter changes to red.
 6. Press the + button to increase the value to 42.
 7. Press ENTER to set the value.
G OFFSET is highlighted in green.
 8. To exit to normal operation, press MENU or wait for the OSD to timeout.

6.2.1 The Main Menu

[Table 3](#) defines the Main menu parameters and functions.

Table 3: The Main Menu Parameters and Functions

Parameter	Function		
DISPLAY	Sets the output resolution, size and aspect ratio (see Table 4)		
CONTRAST	Sets the output contrast	Value range: 0-255	Default: 105
BRIGHTNESS	Sets the output brightness	Value Range: 0-192	Default: 96
COLOR	Sets the output color parameters (see Table 5)		
SDI AUDIO	Selects which embedded audio to output: Group 1, Group 2, Group 3, Group 4, Auto ¹ , Off ² Default: Auto		
FACTORY RESET	Resets all parameters to factory defaults		
INFORMATION	Displays current input resolution, output resolution and firmware revision		
AUTO SYNC OFF	When on, this de-activates the output after a few minutes if no input is present ³		
EXIT	Exits the Main menu		

6.2.2 The Display Submenu

The Display submenu sets the display output resolution, size and aspect ratio.

[Table 4](#) defines the display output parameters.

Table 4: The Display Submenu Parameters

Parameter	Parameters	Factory Default
OUTPUT	PAL, NTSC (PAL: 768x567i, NTSC: 720x480i)	NTSC
SIZE	Sets the output size/aspect ratio: Full, Pan scan, Letter box, Under 2, Under 1, Over scan	Full
EXIT	Exits the Display menu	

¹ When set to Auto, the unit searches for the lowest group number which has audio and selects this audio group

² Audio is not outputted

³ Useful, for example, when the output is connected to a projector, and the projector will automatically shut down when it has no input

6.2.3 The Color Submenu

The Color submenu sets the display output color parameters. [Table 5](#) defines the color output parameters.

Table 5: The Color Submenu Parameters

Parameter	Function	Value Range	Factory Default
R	Sets the output red value	0-255	128
G	Sets the output green value	0-255	128
B	Sets the output blue value	0-255	128
R OFFSET	Sets the output red signal level offset	0-63	32
G OFFSET	Sets the output green signal level offset	0-63	32
B OFFSET	Sets the output blue signal level offset	0-63	32
EXIT	Exits the Color submenu		

7 Technical Specifications

[Table 6](#) lists the technical specifications of the **VP-505 3G HD-SDI to Video Scan Converter**.

Table 6: Technical Specifications¹ of the VP-505 3G HD-SDI to Video Scan Converter

INPUT:	1 SDI/HD-SDI/3G HD-SDI on a BNC connector	
OUTPUTS:	VIDEO:	1 SDI/HD-SDI/3G HD-SDI on a BNC connector (loop)
		1 Composite video on a BNC connector
	AUDIO:	1 Y/C (s-Video) on a 4-pin s-Video connector
		1 Unbalanced stereo audio on 2 RCA connectors
OUTPUT RESOLUTIONS:	PAL, NTSC	
OUTPUT SIZE:	Full, Over scan, Under 1, Under 2, Letter box, Pan scan	
PROCESSING DELAY:	30ms	
CONTROLS:	Menu, ENTER, – and Freeze front panel buttons	
POWER SOURCE:	5V DC, 1.25A	
OPERATING TEMPERATURE:	0° to +55°C (32° to 131°F)	
STORAGE TEMPERATURE:	-45° to +72°C (-49° to 162°F)	
HUMIDITY:	10% to 90%, RHL non-condensing	
D MENSIONS:	18.8cm x 11.3cm x 2.6cm (7.4" x 4.5" x 1") W, D, H	
WEIGHT:	0.57kg (1.26lbs) approx.	
ACCESSORIES:	Power supply	
OPTIONS:	RK-T2B 19" rack adapter	

¹ Specifications are subject to change without notice

LIMITED WARRANTY

We warrant this product free from defects in material and workmanship under the following terms.

HOW LONG IS THE WARRANTY

Labor and parts are warranted for seven years from the date of the first customer purchase.

WHO IS PROTECTED?

Only the first purchase customer may enforce this warranty.

WHAT IS COVERED AND WHAT IS NOT COVERED

Except as below, this warranty covers all defects in material or workmanship in this product. The following are not covered by the warranty:

1. Any product which is not distributed by us or which is not purchased from an authorized Kramer dealer. If you are uncertain as to whether a dealer is authorized, please contact Kramer at one of the agents listed in the Web site www.kramerelectronics.com.
2. Any product, on which the serial number has been defaced, modified or removed, or on which the WARRANTY VOID IF TAMPERED sticker has been torn, reattached, removed or otherwise interfered with.
3. Damage, deterioration or malfunction resulting from:
 - i) Accident, misuse, abuse, neglect, fire, water, lightning or other acts of nature
 - ii) Product modification, or failure to follow instructions supplied with the product
 - iii) Repair or attempted repair by anyone not authorized by Kramer
 - iv) Any shipment of the product (claims must be presented to the carrier)
 - v) Removal or installation of the product
 - vi) Any other cause, which does not relate to a product defect
 - vii) Cartons, equipment enclosures, cables or accessories used in conjunction with the product

WHAT WE WILL PAY FOR AND WHAT WE WILL NOT PAY FOR

We will pay labor and material expenses for covered items. We will not pay for the following:

1. Removal or installations charges.
2. Costs of initial technical adjustments (set-up), including adjustment of user controls or programming. These costs are the responsibility of the Kramer dealer from whom the product was purchased.
3. Shipping charges.

HOW YOU CAN GET WARRANTY SERVICE

1. To obtain service on you product, you must take or ship it prepaid to any authorized Kramer service center.
2. Whenever warranty service is required, the original dated invoice (or a copy) must be presented as proof of warranty coverage, and should be included in any shipment of the product. Please also include in any mailing a contact name, company, address, and a description of the problem(s).
3. For the name of the nearest Kramer authorized service center, consult your authorized dealer.

LIMITATION OF IMPLIED WARRANTIES

All implied warranties, including warranties of merchantability and fitness for a particular purpose, are limited in duration to the length of this warranty.

EXCLUSION OF DAMAGES

The liability of Kramer for any effective products is limited to the repair or replacement of the product at our option. Kramer shall not be liable for:

1. Damage to other property caused by defects in this product, damages based upon inconvenience, loss of use of the product, loss of time, commercial loss; or:
2. Any other damages, whether incidental, consequential or otherwise. Some countries may not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from place to place.

NOTE: All products returned to Kramer for service must have prior approval. This may be obtained from your dealer.

This equipment has been tested to determine compliance with the requirements of:

- EN-50081: "Electromagnetic compatibility (EMC);
generic emission standard.
Part 1: Residential, commercial and light industry"
- EN-50082: "Electromagnetic compatibility (EMC) generic immunity standard.
Part 1: Residential, commercial and light industry environment".
- CFR-47: FCC* Rules and Regulations:
Part 15: "Radio frequency devices
Subpart B Unintentional radiators"

CAUTION

- Servicing the machines can only be done by an authorized Kramer technician. Any user who makes changes or modifications to the unit without the expressed approval of the manufacturer will void user authority to operate the equipment.
- Use the supplied DC power supply to feed power to the machine.
- Please use recommended interconnection cables to connect the machine to other components.
* FCC and CE approved using STP cable (for twisted pair products)



For the latest information on our products and a list of Kramer distributors visit www.kramerelectronics.com where updates to this user manual may be found. We welcome your questions, comments and feedback.



Caution

Safety Warning:

Disconnect the unit from the power supply before opening/servicing.



P/N: 2900-300013



Rev: 2



Kramer Electronics, Ltd.

Web site: www.kramerelectronics.com

E-mail: info@kramerel.com

P/N: 2900-300013 REV 2